



How to Install a 2-piece Sling in a Winston Chair

1. Remove the old sling.

- Remove the sling rail caps and cut the sling down the middle.
- Pull up both halves of the sling on the chair back remove them through the top of the sling rails. For the seat, stand in front, and pull both halves of the seat sling through the sling rails.
- Remove any support bar that is wedged between the two sling rails. Not all models have support bars.

2. Install the sling in the sling rails for the back.

- Install the sling spline (rod) into the sling pockets leaving an extra inch or two on both ends.
- Sling rails should be attached to the frame. Stand to the side of the chair to install one side of the sling on the chair back. Start at the top and work the sling down one sling rail to the bottom. Support the top of the sling so it doesn't tear on the end of the sling rail while going through the sling rail.
- Remove wrinkles. Before the sling reaches the bottom, hold it tight against the sling rail at the top and pull on the bottom of the sling to pull any wrinkles.
- Remove this sling rail before installing the sling on the other side.
- With the second sling rail still attached, stand to the side and repeat to install the second side of the sling. This sling rail should be attached so the chair can hold the sling rail as you work.

3. Re-attach the sling rail.

Now the sling is installed in both sling rails of the chair back, and only one sling rail is attached.

- Using a blanket to protect the finish, lay the chair on its side so the sling rail is hanging.
- Place the bolts into the loose sling rail.
- Start with the back bolt, and using a drill with a bolt head attachment, press down on the bolt until

it reaches the frame. The bolt should barely reach the frame.

- When the bolt reaches the frame, pull the drill's trigger. Only tighten the bolt half way. Depending on the fabric, it may be necessary to loosen the bolt on the opposite sling rail so the bolt can reach.

- Repeat with the remaining bolts and tighten all bolts completely. The sling is now installed in the chair back.

4. Install the sling in the sling rails for the seat.

Stand in front of the chair and work from front to back of the seat. Follow the steps (#2) used for installing the chair back.

5. Finish.

- Turn the chair upright and cut the excess sling spline.
- Replace the sling rail caps.